



# SHUTTERS

## PAINTING INSTRUCTIONS

### PAINTING INSTRUCTIONS: WOOD AND COMPOSITE ONLY

**DO NOT ALLOW SHUTTERS TO STAY IN THE SUN AND GET HOT PRIOR TO OR AFTER PAINTING.**

- **RAW WOOD AND COMPOSITE.**

- Lightly sand with fine grit sand paper or sanding sponge.
- Dust off all loose dust.
- Spray or brush a coat of wood primer. (Oil or Water Base, Latex are OK)
- Let dry per instructions of primer manufacturer.
- Sand until smooth.
- Clean off dust.
- Spray or brush a coat of paint. (Oil or Water Base, Latex are OK)
- Let dry per instructions of paint manufacturer.
- Sand until smooth.
- Clean off dust.
- Spray or brush a second coat of paint.
- Allow paint to cure per paint manufacturer's instructions prior to installing.

**DO NOT LEAN SHUTTERS AGAINST ONE ANOTHER EVEN IF THE PAINT FEELS DRY. THEY CAN STICK TOGETHER!**

- **PRIMED WOOD AND COMPOSITE.**

- Sand until smooth.
- Clean off dust.
- Spray or brush a coat of paint. (Oil or Water Base, Latex are OK)
- Let dry per instructions of paint manufacturer.
- Sand until smooth.
- Clean off dust.
- Spray or brush a second coat of paint.
- Allow paint to cure per paint manufacturer's instructions prior to installing.
- 

**DO NOT LEAN SHUTTERS AGAINST ONE ANOTHER EVEN IF THE PAINT FEELS DRY. THEY CAN STICK TOGETHER!**